



LHR APP. SHOWN
RHR APP. OPPOSITE

NOTES:
1. SEE SHT 2 FOR APPLICATION SCHEDULE.

6212 WF ELECTRIC STRIKE
MORTISE WOOD FRAME APPLICATION



NOTE: SEE MASTER SHEET NO. 10001 FOR SUGGESTED REINFORCING

TEMPLATE NUMBER: W30222_4SHT 1

DATE: 10-21-98